

# KILO

# VAC



## Directions



### OPEN

1. Grip handle and put thumb on the press button
2. Press down on button & twist cap to the left
3. Pull cap up and remove.

### CLOSE

1. Grip handle and put thumb on the press button
2. Align cap arrows with buttons on the body – press down on button (be sure to keep the cap level)
3. Lower the cap down and twist to the right to lock cap into position.

Do not microwave or put in dishwasher. Hand wash only. Always keep the interior of the cap and the top of the container clean. This will ensure easy open and closure.

When Kilovacs are new – Caps are loose and will get tighter fitting as the container is used. If you are carrying heavier items such as 2.5 pounds of coffee we suggest using a piece of tape to hold cap in locked position until Cap has become tight fitting from prolonged use.

**Recommended for dry goods only.  
Do not freeze with liquids.**